


Explosive view and Spare parts for DJ metering pump



Item	Part name	Qty	Item	Part name	Qty
1	Cap of the valve	2	19	Pin of the spring	1
2	Jacket of the valve	2	20	Adjustment handwheel	1
3	Connection sleeve of valve	2	21	O-ring (4)	1
4	O-ring (1)	2	22	Screw	1
5	Valve seat	2	23	Nut and disc	6
6	Ball Valve	2	24	The body	1
7	Rubber disc		25	Lock of the shaft (1)	1
8	O-ring (2)	2	26	Bearing (1)	1
9	One-way valve	2	27	Eccentric shaft	1
10	O-ring (3)	2	28	Disc	1
11	Pump head	1	29	Bearing (2)	2
12	Diaphragm	1	30	Lock of the shaft (2)	1
13	Enhanced plate	1	31	Lock of the hole	1
14	Oil seal for the shaft	1	32	Gearbox	1
15	Seat of spring	1	33	Motor	1
16	Spring	1	34	Inter Hexagon screws (2)	1
17	Carrier rod	1	35	Inter Hexagon screws (3)	4
18	Inter Hexagon screws (1)	4			