


Explosive view and Spare parts for ES solenoid metering pump



Item	Part Name	Qty	Item	Part Name	Qty	Item	Part Name	Qty
1	Adapter base	1	7	Hexagonal screw (2)	4	13	7 pin aviation connector	1
2	Safety cap	1	8	Display screen	1	14	Electrical cable	1
3	Hexagonal screw (1)	2	9	Protective cover	1	15	Control panel	1
4	Pump body	1	10	Screen cover	1	16	Integrated PCB	1
5	Electromagnet	1	11	Hexagonal screw (3)	2	17	Seal	1
6	Holder	1	12	Hexagonal screw (4)	2			